

CREWSAFE DISPLAY CONSOLE OPERATION GUIDE

STROBE FLASH AND AUDIBLE ALARM
 With no red Tag LED
 Manual alarm has been raised - investigate cause

SOLID BLUE
 Crewsafe network OK

LONG BLUE FLASH
 Network fault detected
 OR (on startup) Network
 being established

SOLID RED
 Router has failed

SOLID GREEN
 Receiving live GPS data

LONG RED FLASH
 Acquiring GPS data

NO ILLUMINATION
 No chart plotter or
 GPS connected

SOLID RED
 Chart plotter or
 GPS turned off
 OR Bad connection

SOLID GREEN
 Tag ON and SAFE

LONG ORANGE FLASH
 Tag LOW BATTERY warning

SOLID ORANGE
 Tag CHARGING in Power Dock

NO ILLUMINATION
 Tag OFF or no Tag assigned
 OR Tag removed by cancelled MOB alarm

SOLID RED WITH STROBE/ALARM
 MOB or DURESS alarm

FAST RED FLASH
 MOB WARNING - waypoint
 being logged

LONG RED FLASH
 MOB or DURESS alarm has
 been muted

TURN ON
 Press and release
TURN OFF
 Press and hold 3 seconds

MUTE ALARM
 Press and release

RAISE GENERAL ALARM
 Press and hold 3 seconds

CANCEL GENERAL ALARM
 Press and hold 3 seconds

CANCEL MOB/OTHER ALARMS
 Press together and hold 5 seconds

Note: Cancels one alarm at a time.
 Cancelling an MOB alarm will remove
 MOB Tag from LED display.
 Bring Tag back within network range to
 re-assign it to the LED display.

DIM DISPLAY
 Press and release (4 settings)

