

CREWSAFE V100

Regional Profiles

	Open Loop	Closed Loop
Maximum Transmission Power	1 watt (W)	500 milliwatt
VHF DSC ALERT		
VHF DSC Message Type	Distress	Distress Relay
VHF DSC Message Destination		
1. All ships 2. Group 3. Up to 8 ships or stations with unique Maritime Mobile Service Identity (MMSI)	1	3
VHF DSC Transmission Delay		
On automatic activation	20 seconds	20 seconds
On manual activation	20 seconds	20 seconds
VHF DSC Transmission Interval		
Phase 1 - from minute 0 to 30	5 minutes	5 minutes
Phase 2 - from minute 31 to end of battery life	10 minutes	10 minutes
VHF VOICE ALERT		
VHF Voice Message Type	Mayday	Not permitted
VHF Voice Channels		
Emergency	16	Not permitted
Test	67	Not permitted
VHF Voice Transmission Delay		
On automatic activation	20 seconds	Not permitted
On manual activation	20 seconds	Not permitted
VHF Voice Transmission Interval		
Phase 1 - from minute 0 to 30	5 minutes	Not permitted
Phase 2 - from minute 31 to end of battery life	10 minutes	Not permitted
SELF TEST		
1. Full function test 2. Full function test without VHF voice	1	2